UC-120 LED WIRING COMPARTMENT

INSTALLATION INSTRUCTIONS



Compartment Box

White two

prong cable



READ, UNDERSTAND, and **FOLLOW** these instructions before installing the equipment.

WARNING


Disconnect the Electrical supply power at the service panel (fuse or circuit breaker box). Failure to do so could result in serious injury or death. Only qualified electricians should install this fixture and the installation MUST conform to the Electrical Code and all local codes and ordinances. Ensure that only proper tools, materials, and equipment are used to complete the installation.

SAFETY

- Proper grounding is required to ensure personal safety.
- Fixture should be mounted in locations where unauthorized personnel will not readily subject it to tampering.
- Do not use this equipment for anything other than its intended purpose.
- Servicing this equipment should be performed by qualified service personnel.
- Save these instructions.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the
 FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential
 installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in
 accordance with the instructions, may cause harmful interference to radio communications.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance Could void the user authority to operate the equipment.

INSTALLATION

- 1. Remove the top cap from the compartment box by loosening top screws.
- 2. Mount the compartment box to the desired location.
- 3. Reattach the top cap to the box by tightening the screws.
- 4. Connect the Black Flex cable to a junction box (not included), as per the wiring instructions.
- 5. Connect the white two prong cable to UC-120 LED.



WIRING

- Check that the line voltage is correct.
- Connect fixture **GROUND** (green) wire to power supply **GROUND** (green) wire.
- Connect fixture WHITE wire to power supply NEUTRAL wire.
- Connect fixture BLACK wire to power supply LINE wire.

